

Amazon Echo Series Setup


Echo Dot 2nd Generation



Addendum 1 of 2


Note: Setting up Smart speaker is supported by the provider Amazon and Google.
Please let users set up it by themselves.

1




Tap DEVICES

2




Tap "+" icon to SETUP

3




Tap ADD DEVICE

4



Tap AMAZON ECHO

5



Tap your ECHO type

6




Tap GENERATION of your Echo

7




Tap CONTINUE

8




Wait for the orange light, and tap CONTINUE

9




! Switch Wi-Fi connect to Amazon-XXX

10




When shown this message, tap CANCEL

11




Tap CONTINUE

12




Tap your Wi-Fi Network

13




Input Wi-Fi network password,
and Tap CONNECT

14




Wait for next screen to display

15



Tap CONTINUE

16




Tap NO, SKIP

17




Tap SKIP

18




Tap SKIP

19




Tap SKIP

20




When this screen appears, Confirm your account name, and Tap it.

21




Tap CONTINUE

22




Tap SKIP

23




Play INTRO

24



Tap CONTINUE

25



Try to say:
"Alexa, what time is it?"

Done setup

